Fitting a Sliding Door Lock on your Staycold Cooler

TRUST THE EXPERIENCE

Step 1

Identifying Parts:

- 1 x Lock Barrel
- 1 x Lock Rasp
- 2 x Screws (M5, 8mm self-tapping metal screws)



Step 2

Align the lock to the required position on the inner door of the 2 sliding doors.

The lock should be placed centrally in the door at a height that is appropriate for the user.





Step 3

Using a 3mm drill bit and the lock rasp as a hole guide, drill 2 holes in the door frame.

*** ONLY DRILL ABOUT 3mm INTO THE FRAME ***

This only to make feeder holes into which the screws will fit – doing this will make the screwing of the screws into the frame much easier.

Drilling too far may damage the glass pack inside of the frame – please be careful.



STAYCOLD INTERNATIONAL

Step 4

Screw the lock rasp to the door frame using the 2 screws.

The screws should be tight, and the lock rasp should not be wobbly.





Step 5

Once the lock rasp is secure, the Lock barrel can then be attached when the doors are shut to secure the unit.

The lock barrel will have a flat side that should be against the side of the other door.





You can also watch a video of the above procedure on our YouTube channel.

Scan the code to follow the link there.

Always use genuine Staycold parts.
See our website for more information as well as other guides and instructions.

Head Office and Factory
South Africa

phone +27 56 819 8097
email info@staycold.oc.za

1 Kakie Strachan Road
PO Box 258 Parys 9585

STAYCOLD INTERNATIONAL